











Continuous run time(approx) on a full battery charge

ML006G

Battery: BL4025

DML816

Battery: BL1860B

















Can be used as a compact stationary lamp with the light head swivelled and folded fully.





Light diffusing lens

- softens the light of LED to reduce glare. provides widespread
- illumination.



Large hook

Light head is rotatable with the flashlight hanging down.



Retractable back into the upper portion of handle

Battery capacity warning

This system warns user by reducing the number of ON LED lights down to 1 before the battery is empty.

3-stage brightness adjustment

High+Medium+Low+OFF

Accessories

Lamp shade

Part No. GM00001326

By attaching to the Cordless Flashlight ML006G / DML816, the irradiation range is widened and the glare of the light source is reduced.





without Lamp shade with Lamp shade





Charging Time

40 Vitarioni Max	Fast Charging DC40RA	DC40RC	18V	DC18RC	DC18SD
BL4020 2.0Ah	22 min	30 min	BL1815N 1.5Ah	15 min	30 min
BL4025 2.5Ah	28 _{min}	38 min	BL1820B 2.0Ah	24 _{min}	45 min
BL4040 4.0Ah	45 min	67 min	BL1830B 3.0Ah	22 min	60 min
BL4050F 5.0Ah	50 min	85 min	BL1840B 4.0Ah	36 _{min}	90 min
			BL1850B 5.0Ah	45 min	110 min
			BL1860B 6.0Ah	55 min	130 min

Cordless Flashlight

ML006G / DML816

ML006G **DML816** Run Time (hrs) Up to: 82 Up to: 75 (Low mode, with BL4040) (Low mode, with BL1860B) High/ Medium/ Low: 800 / 400 / 180 lx High/ Medium/ Low: 500 / 250 / 100 lm (Low mode, with BL 1880 High/ Medium/Low: 800 / 400 / 180 lx High/ Medium/Low: 500 / 250 / 100 lm W/ BL 1830B / BL 1840B / from the light source) Luminous Flux 300/230/100 ml 4W/BL4040: W/BL1830B/BL1840B/ 275 - 408 x 85 x 148 mm BL1850B/BL1860B: (10-7/8 - 16 x 3-3/8 x 5-7/8") 267 - 400 x 79 x 127 mm Dimensions (L x W x H) (10-1/2 - 15-3/4 x 3-1/8 x 5") 0.70 - 1.1 kg (1.5 - 2.4 lbs.) Net weight 1.1 - 1.7 kg (2.4 - 3.8 lbs.) Standard Equipment: Shoulder hook set, Lamp shade

> not covered by EPTA-Procedure Items of standard equipment and specifications may vary by country or area.

Makita Corporation

3-11-8 Sumiyoshi-cho, Anjo, Aichi, 446-8502 Japan